




Simplified Guide to Airzone Interfaces



AIRZONE Blueface



Available for:

- ✓ Flexa 25 Plus
- ✓ Easyzone 25 Plus
- ✓ Acuazone



¹ Options available depending on the configuration and/or the HVAC system

For more information, see the manuals at: www.airzonecontrol.com/aa/en/support

AIRZONE

Blueface

FOR AIDOO



Available for:

✓ Aidoo Pro Line




¹ Options available depending on the configuration and/or the HVAC system
For more information, see the manuals at: www.airzonecontrol.com/aa/en/support

AIRZONE Think



Available for:

- ✓ Flexa 25 Plus
- ✓ Easyzone 25 Plus



— Touch buttons

- - - Informative icons

¹ Options available depending on the configuration and/or the HVAC system

For more information, see the manuals at: www.airzonecontrol.com/aa/en/support

AIRZONE Lite



Available for:

- ✓ Flexa 25 Plus
- ✓ Easyzone 25 Plus
- ✓ Acuazone

If the status LED is on with a **steady light**

The zone is on/active.

If the status LED is **blinking**


If the LED blinks very slowly, the zone is off. It can be turned on again by pressing the LED or from the Airzone Cloud app.

If the LED blinks quickly in red or purple, there is an error. You can check it from the zone navigation menu on a Blueface thermostat or in the Airzone Cloud app.

If the status LED is **off**

The thermostat is in energy-saving mode, which is the default mode. You can configure it from the zone navigation menu on the Blueface thermostat or in the Airzone Cloud app.

The set-point temperature is the desired temperature. The default base temperature is 22 °C, and it can be configured from the Lite Settings option on the Airzone Blueface thermostat or in the Airzone Cloud app.




AIRQ Sensor

Available for:

- ✓ Easyzone 25 Plus
- ✓ Flexa 25 Plus
- ✓ Aidoo Pro





Green
Air quality **Good**



Yellow
Air quality **Medium**



Red
Air quality **Low**



--- Informative icons

Available in Wi-Fi version. Operates autonomously, allowing air-quality monitoring and control of ventilation units.
For more information, see the manuals at: www.airzonecontrol.com/aa/en/support

Airzone Cloud APP





○ Your portable control interface

Available for:



Airzone Cloud

Airzone Cloud
YouTube playlist >>



 * Keep in mind that the display and control features of the Airzone Cloud app depend on the installed Airzone system and the access level/profile type in the Airzone Cloud app.
* Contact your Airzone Cloud app administrator if you need advanced access.



Contact Airzone



airzonecontrol.com

For further questions about navigating our interfaces:

techsupport@airzonecontrol.com



MSTAZX6NSTEN03 | April 2026 Edition

The specifications in this catalogue are valid except for typographical errors and may be subject to modification by the manufacturer without prior notice, as a result of its policy of ongoing product improvement. Reproduction of this catalogue, in whole or in part, is prohibited without the express authorization of Corporación Empresarial Altra. All content is the intellectual property of Corporación Empresarial Altra.